
ELECTRONIC KEYBOARD



Owner's Manual

THE FCC REGULATION WARNING (for USA)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the user's authority to operate this equipment.

CAUTION

The normal function of the product may be disturbed by Strong Electro Magnetic Interference. If so, simply reset the product to resume normal operation by following the owner's manual. In case the function could not resume, please use the product in other location.

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.

Power Supply
Please connect the designated AC adaptor to an AC outlet of the correct voltage.

Do not connect it to an AC outlet of voltage other than that for which your instrument is intended.

Unplug the AC power adaptor when not using the instrument, or during electrical storms.

Connections
Before connecting the instrument to other devices, turn off the power to all units. This will help prevent malfunction and / or damage to other devices.

Location
Do not expose the instrument to the following conditions to avoid deformation, discoloration, or more serious damage:

- Direct sunlight
- Extreme temperature or humidity
- Excessive dusty or dirty location
- Strong vibrations or shocks
- Close to magnetic fields

Interference with other electrical devices
Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

Cleaning
Clean only with a soft, dry cloth.
Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling
Do not apply excessive force to the switches or controls.

Do not let paper, metallic, or other objects into the instrument. If this happens, unplug the AC adaptor from the wall outlet. Then have the instrument inspected by qualified service personnel.

Disconnect all cables before moving the instrument.

Contents

Panel & Display Description
Front Panel....4
Rear Panel....4
Display....5

Setup
Power Supply....6

Connections
Connecting a pair of Headphones....7
Connecting an Amplifier....7
Connecting a Computer....7

Playing the Demos....8

Playing the Voices
Selecting a Voice....8
Sustain....8
Modulation....9
DSP Effect....9
Transpose....9

Playing the Styles
Selecting a Style....10
Playing a Fill-In....10
Sync....10
Accompaniment Volume....10
Tempo....11
Chord Fingering....11
One Touch Setting....12

Memory....13

Chord Dictionary....14

Metronome
Turning on the Metronome....14
Selecting the Beat....14

Playing the Songs
Listening to the Songs....15
Lesson Mode....15

Recording and Playback....16

MIDI Functions
What's MIDI?....17
MIDI Terminals....17


Trouble Shooting....18

Specifications....18

Appendices
Voice List....19
Style List....20
Song List....21
Chord List....22
MIDI Implementation Chart....23

Panel & Display Description

Front Panel



1. POWER ON/OFF
Turn the power on and off.

2. MASTER VOLUME
Adjust the master volume.

3. ACC.VOL
Adjust the accompaniment volume.

4. TEMPO
Adjust the current tempo.

5. START/STOP
Start or stop playing the song in Song Mode.
Start or stop playing the style in Style Mode.

6. SYNC/FILL-IN
Turn the SYNC START on and off.
Play the FILL-IN

7. A.B.C.
Turn the Chord Mode on and off.

8. RECORD
Enter the Record Mode.

9. PLAY
Play back the recorded performance.

10. FUNCTION
Change the adjusted function.

11. SONG
Enter the Song Mode.

12. STYLE
Enter the Style Mode.

13. VOICE
Enter the Voice Mode.


14. O.T.S.
Enter the One Touch Setting Mode.


Rear Panel

23. DC 9V
Connect DC 9V power adaptor (optional).

24. PHONES/OUTPUT
Connect a pair of headphones.
Connect the audio equipment.

25. USB
Connect to a computer.





15. DSP
Turn the DSP effect on and off.

16. CHORD DICT./LESSON
Enter or change the Lesson mode.
Enter the Chord Dictionary.

17. MODULATION
Turn the Modulation effect on and off.

18. SUSTAIN
Turn the Sustain effect on and off.


19. METRONOME
Turn the metronome on and off.

20. +, -, NUMBER KEYS
Select the number or adjust the parameters.

21. STORE
Register the memory.

22. M1-M4
Recall the memory settings.

Display



1.DSP

2.LESSON 1

3.LESSON 2

4.LESSON 3

5.CHORD DIRECT

6. AUTO BASS CHORD

7.TREBLE CLEF

8.BASS CLEF

9.BEAT

10.TEMPO/COUNT

11.ACCOMP VOLUME/ MASTER VOLUME

12.METRONOME

13.MEMORY/PERCUSSION

14.RECORD/PLAY

15.ONE TOUCH SETTING

16.SUSTAIN

17.KEYBOARD

Setup

This section contains information about setting up your instrument and preparing to play. Please go through this section carefully before turning the power on.

Power Supply


You can power the unit either by batteries or by power adaptor. Follow the instructions described below.

Using Batteries
6 pieces of C size (SUM-2 or R-14) or equivalent alkaline batteries must first be installed into the battery compartment.

1. Open the battery compartment cover located on the bottom cabinet of the unit.

2. Insert the batteries, carefully follow the polarity markings on the cabinet.

3. Close the compartment cover, making sure that it locks firmly in place.




Caution:
Do not mix old and new batteries.
Always use same types of batteries.
Always remove the batteries from the unit when it is not being used for an extended period of time.

Using Power Adapter
1. First, please make sure that POWER ON/OFF switch of the instrument is set to OFF.

2. Connect the AC adaptor to the power supply jack.

3. Plug the AC adaptor into an AC outlet. And when turning the power OFF, simply reverse the procedure please. This will automatically cut off the battery power supply.

4. Turn the power ON.




Note:
When the keyboard is not in use or in the time of thunderstorm, please disconnect the power for safety purpose.
A prompt voice sounds every two minutes if there is no operation.

In order to save energy, we have designed the “Automatic Shutdown” function to the keyboard. With this function, the keyboard will shutdown automatically when you have left it idle for more than 30 minutes. If you don’t need this feature, just press and hold the [C2] key (the 1st key) and turn it on.

Connections

Connecting a pair of Headphones


A standard pair of stereo headphones can be connected to the PHONES jack for private practice or late-night playing. The internal stereo speaker system is automatically shut off when a pair of head phones is plugged into this jack.



Note :
Do not listen with the headphones at high volume for long periods of time. Doing so may cause hearing loss.

Connecting an Amplifier


Plug an audio cord into the OUTPUT jack.
Then plug the other end of the cord into LINE IN or AUX. IN of the amplifier.



Note:
To avoid damaging the speakers, please ensure that the volume has been set to the minimum level before connecting the power and other devices.

Connecting a Computer

The instrument receives and transmits MIDI messages via the USB connector.




Playing the Demos

The instrument features 80 demo songs.

1. Press the [STYLE] and [VOICE] buttons simultaneously to start playing the demo.

2. Select a demo song.
Use the number keys, [+] or [-] button to select the desired demo song.



Adjust the volume with the [MASTER VOLUME] buttons. Repeatedly press [VOLUME +] or [VOLUME -] to increase or decrease the volume. The volume ranges from 0 (no sound) to 9 (Maximum) and the current volume level appears on the display.

Press the [STYLE] and [VOICE] buttons simultaneously again or press the [START/STOP] button to stop playing and exit the demo mode.

Note:
In the DEMO mode, all buttons except START/STOP, TEMPO+, TEMPO-, [+], [-], VOLUME+, VOLUME-, POWER ON/OFF will not be available.

Playing Voices


The instrument features 132 voices, including 4 drum kits. Please refer to ***Voice List***.

Selecting a Voice

1. Press the [VOICE] button.
Enter the VOICE mode. LCD shows "VOICE" and the voice number.


2. Select a voice.
Use the number keys, [+] or [-] button to select the voice you want to play.

3. Play the voice.
You can play the keyboard and listen to the selected voice.




Sustain

When the Sustain features in ON, all notes played on the keyboard would have a longer sustain. Press the [SUSTAIN] button to turn the SUSTAIN effect ON or OFF.




Modulation

The Modulation function applies a vibrato effect to notes played on the keyboard. Press the [MODULATION] button while playing the keyboard then you will hear the vibrato effect.




DSP Effect

This function allows you to perform the overall sound in a more realistic effect.
The DSP effect is set to ON when keyboard is power on. Press the [DSP] button to turn on/off the DSP effect.



Transpose

Transpose function allows the overall pitch of the instrument to be transposed up or down by a maximum of 6 semitone increments.



1. Press the [FUNCTION] button until "TPS 0" displays.



2. Press the [+] or [-] button to adjust the pitch of the instrument within 6 semitone.

3. Press the [+] and [-] buttons simultaneously to reset the transpose to **0.**


Playing the Styles

The instrument features 100 styles in a variety of different musical genres. Try selecting some of the different styles (Refer to ***Style List***) and play with the auto accompaniment.

Note:

The styles (91-99 and 00) are the piano styles. If you don't turn on A.B.C. and play a chord, the auto accompaniment does not work.

Selecting a Style



1. Press the [STYLE] button.
Enter the STYLE mode. LCD shows "STYLE" and the style number.

2. Use the number keys, [+] or [-] to select the style you want to play.

3. Press the [START/STOP] button to start the rhythm tracks of the auto accompaniment.




Playing a Fill-In

Simply press the [FILL-IN] button, while the style is playing. The keyboard inserts a variation, then the original style automatically resumes at the end of the current measure.

Note:

For inserting a longer variation, hold down the [FILL-IN] button, The keyboard play the variation until you release the [FILL-IN] button.




Sync

While the style is not playing, press the [SYNC] button. The beat flash, indicating the standby mode of the keyboard.

1. If the A.B.C. is OFF, pressing any key will automatically begins to play the style (rhythm track).


2. If the A.B.C. is ON, pressing any key in the left-hand range of the keyboard will automatically begins to play the style (all tracks).



Accompaniment Volume


Adjust the volume of the accompaniment with the [ACC.VOL] buttons.


Repeatedly press [ACC.VOL +] or [ACC.VOL -] to increase or decrease the volume. The volume ranges from 0 (no sound) to 9 (Maximum) and the current accompaniment volume level appears on the display.



Tempo

Each style of the instrument has been programmed with a default tempo; however, this can be changed by using the [TEMPO+] or [TEMPO-] buttons.






1. Use the [TEMPO+] or [TEMPO-] button to change the tempo. The value ranges from 40 to 240.

2. Hold down the [TEMPO] buttons can change the tempo quickly**.**

3. Press the [TEMPO+] and [TEMPO-] buttons simultaneously to restore the default tempo setting.


Chord Fingering

1. Press the [A.B.C.] button, "A.B.C." appears on the left side of the display. Now, the keyboard is divided into two parts. The 19 keys on the left of the keyboard are called accompaniment keys. The accompaniment keys you pressed determine the type of chords that you played.




2. Press the accompaniment keys**,** the corresponding chord will display on LCD**.**

Single Finger
Single finger type not only can detect single finger but also can detect multi finger. And the single finger makes it easily to play chords through only one, two or three keys. Including major, minor, seventh, and minor seventh chord. Refer to relevant picture on the right for details.




Multi Finger
Multi finger type only can recognize those chords have listed in the chord list, and also can be found in the dictionary function.



One Touch Setting


One Touch Setting is a convenient function that allows you to automatically play a preset voice to match a selected style you have changed.

Follow these steps to activate One Touch Setting.



1. Press the [O.T.S.] button to turn on the One Touch Setting for current style. “O.T.S.” appears**.**

2. Press one of the One Touch Setting buttons [M1]-[M4]. Voice match the selected style can be instantly recalled with just a single button press.



3. Press the [O.T.S.] button again to quit One Touch Setting mode**,** “O.T.S.” disappears**.**

Note:
A.B.C. is automatically turned on in O.T.S. mode.


When the style is changed, the matched voice will be changed automatically in O.T.S. mode.


Memory

There are 4 memories (M1-M4).

1. While holding the [STORE] button, press one of the MEMORY buttons: [M1] - [M4] to register the panel settings. The new settings will replace the previous memory data. The settings include the number of voice, the number of style, tempo, beat value, sustain effect, etc.

2. Press one of the MEMORY buttons: [M1] - [M4] to recall the panel settings.





Note:
The stored settings can not be recalled when the One Touch Setting function is on.
The stored settings will be returned to the default settings after you turned off the power.

Chord Dictionary


If you know the name of a chord but don't know how to play it, you can use the Chord Dictionary function.



1. Press the [CHORD DICT.] button to enter this mode, the LCD displays " d iC7 ", the Chord Type and Chord Notes.



2. In this mode, the key above G#3 are used to assign the Chord Type, the keys above C5 are used to assign the Chord Root. When the Chord Type and Chord Root are confirmed, the LCD will display the Chord and its keyboard position.



3. Play the chords on the keyboard according to the display. If you press the correct notes, you will hear a prompt applause sound.

4. Press the [CHORD DICT.] button again to exit this mode.


Metronome

Turning on the Metronome

1. Press the [METRONOME] button to turn on the metronome.


2. Press the [METRONOME] button again to turn off the metronome.

3. Press the [TEMPO+] / [TEMPO-] button to change the tempo of the metronome.



Selecting the Beat

1. Press the [FUNCTION] button until " bE7 4 " displays.




2. Press the [+] or [-] button to change the beat value: 0, 2, 3, 4, 5, 6, 7, 8, 9. The default value is 4.




The instrument features 80 songs (Refer to ***Song List***). Each song can be practiced in LESSON mode.

Listening to the Songs




1. Press the [SONG] button to enter the song mode. It will play all songs circularly. The display indicates "SONG" and the number of the current song. Press the [SONG] button again, it will stop the song and exit the song mode.

2. In song mode, use the number keys, [+] or [-] button to select a song.



3. Once you start playing a song by pressing [START/STOP] button, it will play current song repeatedly. Press the [START/STOP] button again, it will stop the current song but not exit the song mode.

4. Use the [TEMPO+] or [TEMPO-] button to change the tempo of the current song.



5. When the song is stopped, press [STYLE], [VOICE], [DEMO] to exit the song mode.

Lesson Mode

In the instrument, there are 3 different ways to practice the songs: time value training, note correction training, melody off. And the keyboard has a grading system to help you to know well about your progress.




1. In Song mode, press the [LESSON] button to enter the lesson mode or switch the lesson mode.



2. Press the [START/STOP] button to start learning. The LCD will display the note need to be played.

3. Press the [START/STOP] button again to stop learning.



4. There are 3 lesson modes and a grading system.

Lesson 1: the keyboard only grades the time value of the playing, don't care the correction of the note.
Lesson 2: the keyboard only grades your practice by the note; don't care about the correctness of the timing. Only when you play the correct note, the song will continue to the next note.
Lesson 3: the keyboard will score your practice by the correction of the time value and note.
Grade: In lesson mode, when you finished learning the current the song, the keyboard will play the prompt sound to tell you the level you get.

Level 1: Ok
Level 2: Good
Level 3: Very Good
Level 4: Excellent

After grading, the song will be playing again, you can learn it again.

Recording and Playback

You can record your performance (up to 200 notes), and the accompaniment.

1. Press the [RECORD] button, the “REC” appears, the beat flashes.


2. Play the notes you want to record or press the [START/STOP] button to start recording. If you want to record your performance accompanied with the style, please turn on the A.B.C., and play the chords on the left of the keyboard.

3. Press the [RECORD] button again to stop recording. The “REC” disappears.

4. Press the [PLAY] button to play the notes you recorded. The “PLAY” appears.

5. Press the [PLAY] button again to stop it. The “PLAY” disappears.

Note:
If you turned off the keyboard, the data you have recorded will be lost.



By using the MIDI functions you can expand your musical possibilities. This section explains what MIDI is, and what it can do, as well as how you can use MIDI on your instrument.


What's MIDI?

MIDI (short for Musical Instrument Digital Interface) allows a wide variety of electronic musical instruments, computers and other related devices to connect and communicate with one another. MIDI carries event messages that specify notation, pitch and velocity, control signals for parameters such as volume, vibrato, audio panning, and program change information to change the voice selections.

The instrument can output the real-time playback information via MIDI and control external MIDI devices. The instrument can also accept incoming MIDI messages and generate sound accordingly.

MIDI Terminals

MIDI Connection
The electronic keyboard is equipped with a standard USB interface instead of conventional MIDI IN and MIDI out connectors. The USB interface allows the keyboard to be connected to a computer without the need to separately purchase a MIDI interface for the computer. Most computers will automatically recognize the keyboard as a MIDI interface, allowing MIDI messages to be received from, or sent to, music programs running on the computer.
To connect the keyboard to a computer you will need a standard USB A-B cable (not supplied) and suitable software such a music sequencing program (not supplied).



Note:
Activate the computer from a sleep/suspended/standby mode before connecting the USB cable.
Connect the USB cable to the instrument and a computer before turning the power of the instrument on.

Troubleshooting

Problem	Possible Cause and Solution
The speakers produce a “pop” sound whenever the power is turned ON or OFF.	This is normal and is no cause for alarm.
No sound results when the keyboard is played.	Make sure the master volume is set at appropriate levels.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it further away from the instrument.
The auto accompaniment does not play back even Sync is in standby condition and a key is pressed.	You may be trying to start accompaniment by playing a key in the right-hand range of the keyboard. To start the accompaniment with Sync Start, make sure to play a key in the left-hand range of the keyboard.

Specifications

Keyboard
49

Display
Multi-functional LCD

Polyphony
32

Voice
132, including 4 drum kits

Style
100

Song
80

Demo
80

Tempo
40-240

Registration Memory
4

Control button
Power on/off switch, Master Volume+/-, ACC Volume+/-., Tempo+/-, A.B.C., Function, Style, Voice, Song, Lesson/Chord Dict., Store, M1-M4, O.T.S., Modulation, Number Keys, +, -, Metronome, Sustain, DSP

Accompaniment Control
Start/Stop, Sync/Fill

Record Function
Record, Play

Connectors
DC IN, PHONES/OUTPUT, USB

Power Supply
DC 9V

Speaker
3W+3W

Dimensions
795(W)x315 (D)x120(H) mm

Weight
3.6Kg（without batteries）

* All specifications and appearances are subject to change without notice.

No.	Name	abbr.
PIANO		
1	Acoustic Grand Piano	Grand Pno
2	Bright Acoustic Piano	Bright Pno
3	Electric Grand Piano	E.Grand Pno
4	Honky-Tonk Piano	Honky-Tonk
5	Rhodes Piano	Rhodes Pno
6	Chorus Piano	Chorus Pno
7	Harpsichord	Harpsichord
8	Clavichord	Clavi
MALLET		
9	Celesta	Celesta
10	Glockenspiel	Glockenspiel
11	Music Box	Music Box
12	Vibraphone	Vibraphone
13	Marimba	Marimba
14	Xylophone	Xylophone
15	Tubular Bells	Tubular Bells
16	Dulcimer	Dulcimer
ORGAN		
17	Hammond Organ	Hammond Org
18	Percussive Organ	Perc Org
19	Rock Organ	Rock Org
20	Church Organ	Church Org
21	Reed Organ	Reed Org
22	Accordion	Accordion
23	Harmonica	Harmonica
24	Tango Accordion	Tango Acd
GUITAR&BASS		
25	Acoustic Guitar (Nylon)	Nylon Gtr
26	Acoustic Guitar (Steel)	Steel Gtr
27	Electric Guitar (Jazz)	Jazz Gtr
28	Electric Guitar (Clean)	Clean Gtr
29	Electric Guitar (Muted)	Muted Gtr
30	Overdriven Guitar	Overdriven
31	Distortion Guitar	Distortion
32	Guitar Harmonics	Harmonics
33	Acoustic Bass	Acoustic Bass
34	Electric Bass (Finger)	Finger Bass
35	Electric Bass (Pick)	Pick Bass
36	Fretless Bass	Fretless Bass
37	Slap Bass 1	Slap Bass 1
38	Slap Bass 2	Slap Bass 2
39	Synth Bass 1	Synth Bass 1
40	Synth Bass 2	Synth Bass 2
STRINGS		
41	Violin	Violin
42	Viola	Viola
43	Cello	Cello
44	Contrabass	Contrabass
45	Tremolo Strings	Tremolo Strs
46	Pizzicato Strings	Pizzicato Strs
47	Orchestra Harp	Orchestra Harp
48	Timpani	Timpani
ENSEMBLE		
49	Strings Ensemble 1	Strings Ens 1
50	Strings Ensemble 2	Strings Ens 2
51	Synth Strings 1	Synth Strs 1
52	Synth Strings 2	Synth Strs 2
53	Choir Aahs	Choir Aahs
54	Voice Oohs	Voice Oohs
55	Synth Voice	Synth Voice
56	Orchestra Hit	Orchestra Hit
BRASS		
57	Trumpet	Trumpet
58	Trombone	Trombone
59	Tuba	Tuba
60	Muted Trumpet	Muted Trumpet
61	French Horn	French Horn
62	Brass Section	Brass Section
63	Synth Brass 1	Synth Brass 1
64	Synth Brass 2	Synth Brass 2
REED		
65	Soprano Sax	Soprano Sax
66	Alto Sax	Alto Sax
67	Tenor Sax	Tenor Sax
68	Baritone Sax	Baritone Sax
69	Oboe	Oboe
70	English Horn	English Horn
71	Bassoon	Bassoon
72	Clarinet	Clarinet
PIPE		
73	Piccolo	Piccolo
74	Flute	Flute
75	Recorder	Recorder
76	Pan Flute	Pan Flute
77	Bottle Blow	Bottle Blow
78	Shakuhachi	Shakuhachi
79	Whistle	Whistle
80	Ocarina	Ocarina
LEAD & PAD		
81	Lead 1 (Square)	Square
82	Lead 2 (Sawtooth)	Sawtooth
83	Lead 3 (Calliope lead)	Calliope
84	Lead 4 (Chiff lead)	Chiff
85	Lead 5 (Charang)	Charang
86	Lead 6 (Voice)	Voice
87	Lead 7 (Fifths)	Fifths
88	Lead 8 (Bass&Lead)	Bass&Lead
89	Pad 1 (New Age)	New Age
90	Pad 2 (Warm)	Warm
91	Pad 3 (Polysynth)	Polysynth
92	Pad 4 (Choir)	Choir
93	Pad 5 (Bowed)	Bowed
94	Pad 6 (Metallic)	Metallic
95	Pad 7 (Halo)	Halo
96	Pad 8 (Sweep)	Sweep
SYNTH SFX		
97	FX 1 (Rain)	Rain
98	FX 2 (Soundtrack)	Soundtrack
99	FX 3 (Crystal)	Crystal
100	FX 4 (Atmosphere)	Atmosphere
101	FX 5 (Brightness)	Brightness
102	FX 6 (Goblins)	Goblins
103	FX 7 (Echoes)	Echoes
104	FX 8 (Sci-Fi)	Sci-Fi
ETHNIC		
105	Sitar	Sitar
106	Banjo	Banjo
107	Shamisen	Shamisen
108	Koto	Koto
109	Kalimba	Kalimba
110	Bagpipe	Bagpipe
111	Fiddle	Fiddle
112	Shanai	Shanai
PERCUSSIVE		
113	Tinkle Bell	Tinkle Bell
114	Agogo	Agogo
115	Steel Drums	Steel Drums
116	Woodblock	Woodblock
117	Taiko Drum	Taiko Drum
118	Melodic Tom	Melodic Tom
119	Synth Drum	Synth Drum
EFFECTS		
120	Effects 1	Effects 1
121	Effects 2	Effects 2
122	Effects 3	Effects 3
123	Effects 4	Effects 4
124	Effects 5	Effects 5
125	Effects 6	Effects 6
126	Effects 7	Effects 7
127	Effects 8	Effects 8
128	Effects 9	Effects 9
DRUM		
129	Standard Kit	Standard
130	Room Kit	Room
131	Power Kit	Power
132	Electronic Kit	Electronic

Style List

No.	Name	abbr.
BEAT & POP		
1	8 Beat 1	8 Beat 1
2	8 Beat 2	8 Beat 2
3	8 Beat 3	8 Beat 3
4	8 Beat 4	8 Beat 4
5	60's 8 Beat	60's 8 Beat
6	8 Beat Ballad	8 Beat Ballad
7	8 Beat Rock	8 Beat Rock
8	16 Beat 1	16 Beat 1
9	16 Beat 2	16 Beat 2
10	16 Beat Pop	16 Beat Pop
11	16 Beat Shuffle	16 Beat Shuffle
12	Ballad 1	Ballad 1
13	Slow Ballad	Slow Ballad
14	16 Beat Ballad	16 Beat Ballad
15	Unplugged	Unplugged
ROCK		
16	Rock	Rock
17	Pop Rock	Pop Rock
18	Fast Rock	Fast Rock
19	Slow Rock 1	Slow Rock 1
20	Slow Rock 2	Slow Rock 2
21	Rock & Roll	Rock & Roll
22	Heavy Metal	Heavy Metal
23	Blues Boogie	Blues Boogie
24	Blues	Blues
25	Shuffle	Shuffle
26	Blues Shuffle	Blues Shuffle
27	Rock Shuffle	Rock Shuffle
28	Charleston	Charleston
DANCE		
29	Disco 1	Disco 1
30	Disco 2	Disco 2
31	Disco Funk	Disco Funk
32	Dance	Dance
33	House 1	House 1
34	House 2	House 2
35	Rap	Rap
36	Euro Beat	Euro Beat
37	Hip Hop	Hip Hop
38	Techno	Techno
SOUL & FUNK		
39	Funky Pop	Funky Pop
40	Jazz Funk	Jazz Funk
41	Cool Funky	Cool Funky
42	Soul 1	Soul 1
43	Soul 2	Soul 2
44	Soul Shuffle	Soul Shuffle
45	Soul Blues	Soul Blues
46	R & B	R & B
47	6/8 Gospel	6/8 Gospel
48	Pop Groove	Pop Groove
JAZZ		
49	Swing 1	Swing 1
50	Cool Jazz	Cool Jazz
51	Pop Swing	Pop Swing
52	Swing Fox	Swing Fox
53	Big Band	Big Band
54	Big Band Medium	Big Band Medium
55	Jazz Waltz 1	Jazz Waltz 1
56	Ragtime	Ragtime
57	Dixieland	Dixieland
58	Quick Step	Quick Step
COUNTRY		
59	Country 1	Country 1
60	Country 2	Country 2
61	Pop Country	Pop Country
62	Country Rock	Country Rock
63	Country Folk	Country Folk
64	3/4 Country	3/4 Country
65	Country Waltz	Country Waltz
66	Country Shuffle	Country Shuffle
67	Country Boogie	Country Boogie
68	Country Blues	Country Blues
69	Country Quick Step	Country Quick Step
70	Bluegrass	Bluegrass
LATIN		
71	Bossa Nova 1	Bossa Nova 1
72	Bossa Nova 2	Bossa Nova 2
73	Rhumba	Rhumba
74	Pop Rhumba	Pop Rhumba
75	Cha Cha	Cha Cha
76	Pop Cha Cha	Pop Cha Cha
77	Tango	Tango
78	Jazz Samba	Jazz Samba
79	Reggae	Reggae
80	Pop Reggae	Pop Reggae
TRADITIONAL		
81	March 1	March 1
82	March 2	March 2
83	German March	German March
84	6/8 March 1	6/8 March 1
85	Polka	Polka
86	Pop Polka	Pop Polka
87	Waltz 1	Waltz 1
88	Slow Waltz	Slow Waltz
89	Vienna Waltz	Vienna Waltz
90	Musette	Musette
PIANO		
91	8 Beat	8 Beat
92	Ballad 2	Ballad 2
93	Boogie	Boogie
94	Jazz	Jazz
95	Swing 2	Swing 2
96	Jazz Waltz 2	Jazz Waltz 2
97	Twist	Twist
98	March	March
99	6/8 March 2	6/8 March 2
00	Waltz 2	Waltz 2

No.	Name
FAVORITE	
1	The Old Gray Mare
2	In The Rain
3	Jeanie With The Light Brown Hair
4	American Patrol
5	Heidenroslein
6	Music Box Dancer
7	Rondo
8	The Melody Of Yesterday
9	It's Been A Long, Long Time
10	Chant Sans Paroles
11	Water Music
12	The Entertainer
13	Огонек
14	Five Hundred Miles
15	Old Folks At Home
16	O Sole Mio
17	Sonata
18	Allegro In bB
19	The Red Sarafan
20	Dance De Mirlitons
21	Nocturne
22	Air On The G String
23	Canon
24	Minuet In G
25	Beautiful Dreamer
FOLK & COUNTRY	
26	Danny Boy
27	My Bonnie
28	Skip To My Lou
29	Katyusha
30	Red River Valley
31	The Sideway
32	Dance Of Russia
33	House Of Rising Sun
34	Starlight Waltz
35	Home On The Range
36	The Blue Bells Of Scotland
37	Annie Laurie
38	Trumpet
39	Country
40	Jambalaya
41	Bridge
42	Sippin' Cider Through A Straw
JAZZ & FUSION	
43	June Samba
44	Guitar & Saxphone
45	The Hip Hop's Night
46	Blue Lunch
47	Cobweb
48	Wine
49	Jazz Old Man
50	Carlos
CHRISTMAS	
51	Ave Maria
52	Joy To The World
53	Santa Claus Is Coming To Town
54	Silent Night
55	Amazing Grace
56	Oh! Susanna
57	Battle Hymn Of The Republic
58	Carry Me Back To Old Virginny
59	Camptown Races
60	Dark Eyes
PIANO	
61	Fur Elise
62	Bagatelle No. 3
63	Musette in D
64	Prelude in G
65	Turkish Rondo
66	Four Little Swans
67	Did You Ever See A Lassie
68	Spring
69	Impromptu
70	Gavotte
71	Nocturne
72	Pizzicato Polka
73	Moment Musical
74	The Rag-Time Dance
75	All Kind Of My Everything
76	Valse No. 6 "Petit Chien"
77	Rondeau
78	The Chrysanthemum
79	Invention A 2 Voix
80	Jesus, Saviour, Pilot Me

Chord List

No.	Chord Name/[Abbreviation]	Normal Voicing	Chord (C)	Display
0	Major [M]	1-3-5	C	C
1	Major sixth [6]	1-(3)-5-6	C6	C6
2	Major seventh [M7]	1-3-(5)-7	CM7	CM7
3	Major add ninth [Madd9]	1-2-3-5	Cmadd9	CM9
4	Augmented [aug]	1-3-#5	Caug	Caug
5	Minor [m]	1-b3-5	Cm	Cm
6	Minor sixth [m6]	1-b3-5-6	Cm6	Cm6
7	Minor seventh [m7]	1-b3-(5)-b7	Cm7	Cm7
8	Minor major ninth [mM7]	1-b3-(5)-7	CmM7	CmM7
9	Diminished [dim]	1-b3-b5	Cdim	Cdim
10	Diminished seventh [dim7]	1-b3-b5-6	Cdim7	Cdim7
11	Seventh [7]	1-3-(5)-b7	C7	C7
12	Seventh suspended fourth [7sus4]	1-4-5-b7	C7sus4	C7sus4
13	Suspended fourth [sus4]	1-4-5	Csus4	Csus4

Function		Transmitted	Recognized	Remarks
Basic	Default	1ch	1-16ch	
Channel	Changed	×	×	
	Default	×	3	
Mode	Messages	×	3	
	Altered	**********	×	
Note		0—127	0—127	
Number	True voice	**********	0—127	
Velocity	Note on	○ 9nH,V=64	○ 9nH,V=1-127	
	Note off	×(9nH,V=0)	×(9nH,V=0; 8nH,V=0-127)	
After Touch	Keys	×	×	
	Chs	×	×	
Pitch Bend		×	○	
Control	0	×	○	Bank Select
Change	1	×	○	Modulation
	5	×	○	Portamento Time
	6	×	○	Data Entry
	7	×	○	Volume
	10	×	○	Pan
	11	×	○	Expression
	64	×	○	Sustain Pedal
	65	×	○	Portamento ON/OFF
	66	×	○	Sostenuto Pedal
	67	×	○	Soft Pedal
	80	×	○	Reverb Program
	81	×	○	Chorus Program
	91	×	○	Reverb Level
	93	×	○	Chorus Level
	120	×	○	All Sound Off
	121	×	○	Reset All Controllers
	123	×	○	All Notes Off
Program		○	○	
Change	:true	**********	0—127	
System	Exclusive	×	×	
System	:Song Position	×	×	
Common	:Song Select	×	×	
	:Tune	×	×	
System	:Clock	×	×	
Real Time	:Commands	×	×	
Aux	:Local ON/OFF	×	×	
	:All Notes Off	×	○	
Messages	:Active Sense	×	○	
	:Reset	×	○	
Note:				

- Mode 1: OMNI ON, POLY
- Mode 2: OMNI ON, MONO
- Mode 3: OMNI OFF, POLY
- Mode 4: OMNI OFF, MONO

○: YES
×: NO